

HERON
INSTRUMENTS INC.
Groundwater Monitoring

SKINNY DIPPER Water Level Meter

Length options: 100ft/30m to 500ft/150m

Warranty: 3 years, probe 1 year

The **SKINNY DIPPER** water level meter is ideal for measuring **static** water levels in narrow wells, boreholes, tubes and piezometers. The slim line tape and **1/4" probe** enable users to take readings while the pump is still in the well, whereas wider tapes may get tangled.

The **1/4" polyethylene tape**, available in metric (mm) or engineering scale (1/100'), is marked with black and red graduations, making measurements easy to read in the field.


Features included with the SKINNY DIPPER:

- **Electronic Module (IP65)** – removable for easy cleaning and servicing
- **Probe (IP68)** – 1/4" fully submersible up to 100m/300' for 20 minutes
- **Tape** – extruded 1/4" **Polyethylene** tape – markings in metric (mm) or engineering scale (1/100')
- **Padded Carry Case** – to protect your **precision** water level meter from the elements
- **Tape Guide and Hanger** – to support the meter at the well head and to **protect** the tape from sharp edges on the well casing
- **Vinyl Holding Grip** – molded to the frame, **ergonomic easy grip**
- **Winding Handle** – custom made for **easy rewinding** with gloved hands



HERON INSTRUMENTS INC.

447 Moxley Rd. | Dundas, ON Canada L9H 5E2 | 1-800-331-2032 | info@heroninstruments.com

Please visit our website for more information on the complete Heron line.  Made in Canada

www.heroninstruments.com