



**HERON**  
INSTRUMENTS INC.  
Groundwater Monitoring

## dipper-Tag tag line

Length options: 500ft or 150m

Warranty: 3 years

The economical **dipper-Tag** is a **multi-purpose** unit designed for use when installing or monitoring wells. The 316 grade s/s weight that comes with the **dipper-Tag** can be used for measuring to the bottom of a well, or the depth to the top of a bentonite layer or backfill sand. The spring release clip allows the user to exchange the weight to other available accessories such as our s/s **plopper** for measuring static water levels **acoustically** or one of our **dipperLogs** to measure water levels and temperature for **short term** analysis. The **dipper-Tag** can also be used with third party accessories (i.e bailers for water sampling).

In order to keep this unit cost effective it is only available in one tape length, 500' or 150m.

### Features included with the dipper-Tag:

- **Spring Release Clip** – forged stainless and chrome plated
- **Weight** – 316 grade stainless steel, 750 grams
- **Tape** – polyethylene, reinforced with **Kevlar** – markings in metric (mm) or engineering scale (1/100')
- **Carry Bag** – to **protect** your water level meter from the elements
- **Tape Guide and Hanger** – to support the meter at the well head and to **protect** the tape from sharp edges on the well casing
- **Vinyl Holding Grip** – molded to the frame, **ergonomic easy grip**
- **Winding Handle** – custom made for **easy rewinding** with gloved hands


### Available Accessory:

- **Plopper** – 1 ½", for measuring static water levels acoustically



**HERON INSTRUMENTS INC.**

447 Moxley Rd. | Dundas, ON Canada L9H 5E2 | 1-800-331-2032 | info@heroninstruments.com

Please visit our website for more information on the complete Heron line.  Made in Canada

[www.heroninstruments.com](http://www.heroninstruments.com)